

ASSEMBLY INSTRUCTIONS FOR GAS TIGHT ADAPTORS FOR SYALON TUBES

Parts of the adapter:

- ❶ Upper part adapter, SS with G 3/4" inside thread and G1" outside thread for connection to the bottom part of the adapter ❷
- ❷ Bottom part adapter with G1" inside thread for connection to the top part of the adapter ❶
- ❸ Small round graphite gasket
- ❹ Large round graphite gasket
- ❺ Two mild steel half rings



Adapter parts with Syalon protection tube, text above describes the numbers

Gas tight assembly of adapter to the tube:

Disassemble the adapter. Take the two half rings ❺ and the smaller graphite gasket out of the bottom part ❷

Put the split mild steel rings ❺ around the recess of the Syalon tube (see picture above).

Starting from the closed end of the Syalon tube, slide the bottom part of the adapter with the thread first, over the tube. Make sure the two halves of the SS ring are around the recess of the Syalon tube when the bottom part of the adapter has been slid all the way up.

Put the smaller graphite gasket ❸ on top of the Syalon tube (see picture above).

Screw the upper part of the adapter ❶ with the larger graphite gasket ❹ around the outside thread, on the bottom part and tighten with your hands.